

Installation example „Thermoplastic Elastomers“

Technical information

When processing thermoplastic elastomers, please observe the following recommendations to ensure reliable demolding:

- The distance "L" should decrease with the Shore hardness value.
- A centering cone should be provided.
- This application instruction applies to elastomers in the medium Shore hardness range up to 100 Shore A.

